

Elthum Ion Dattery Test Summary			
(a) Model Number	SB-U98/PD (Serial No. BD1Cxxxxxxxx / BD2Cxxxxxxxx)		
(b) Product manufacturer	IDX Company, Ltd.		
Address	6-28-11 Shukugawara, Tama-ku, Kawasaki-shi,		
	Kanagawa-ken, 214-0021, Japan		
Telephone	+81-44-850-8801		
e-mail	idx.japan@idx.tv		
URL	https://www.idx.tv/		
(c) Test laboratory	Shenzhen NTEK New Energy Technology Co., Ltd.		
Address	Building 2, Shuoyi Industrial Park, Jinglong Industrial		
	Zone, Zhenlong, Huiyang District, Huizhou, Guangdong,		
	China.		
Telephone	400-809-9068		
e-mail	Quality@ntekbat.org.cn		
URL	http://www.ntekbat.org.cn		
(d) Identification number	P22081300701 / P24121604701		
(e) Date of test report	2022-08-30 / 2024-12-16		
(f) Description of Product	Lithium ion Rechargeable Battery		
Nominal Voltage	14.4V / 14.54V		
Capacity(mAh/Wh)	6600mAh,96Wh / 6620mAh,97Wh		
Lithium equivalent content	7.92g / 7.94g		
Mass	490g / 490g		
Physical description	Battery with outer case		

(g) Test Result

No.	Test Item	Test Results	No	ote
T1	Altitude Simulation	Pass		
T2	Thermal Test	Pass	First cycle fully After 25 c charged 4 Batteries charged 4	After 25 evole fully
Т3	Vibration	Pass		charged 4 Batteries
T4	Shock	Pass		chargeu 4 batteries
T5	External Short Circuit	Pass		
Т6	Impact	Pass	First cycle 50% charged 5 cells	After 25 cycle 50% charged 5 cells
Т7	Overcharge	Pass	First cycle fully charged 4 Batteries	After 25 cycle fully charged 4 Batteries
Т8	Forced Discharge	Pass	First cycle fully discharged 10 cells	After 25 cycle, fully discharged 10 cells

%The Battery pack Package complies with the requirements of 3m Stacking test according to regulations.

(h) Assembled Battery Testing Requirements N/A.

(i) Reference edition	UN Manual of Tests and Criteria,
	ST/SG/AC.10/11/Rev.7/Section38.3 /
	ST/SG/AC.10/11/Rev.8/Section38.3
(j) Signature	Tatsuva Ishiguro
	Tatsuya <sup>1</sup> Ishiguro, General Manager
	Technical Development, Products Division
	IDV Company 1td

# IDX Company, Ltd.

# IDX Company, Ltd.



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv

> Issued: January 1, 2025 No. XC11T0278-29

# SAFETY DATA SHEET FOR PRODUCT

# **1. PRODUCT AND COMPANY IDENTIFICATION**

- Product Name :
- Product code :

Lithium Ion Rechargeable Battery Pack IPL-150, IPL-98, DUO-C198, DUO-C150, DUO-C98, DUO-C190, DUO-C95, DUO-150, DUO-95, CUE-D300, CUE-D150, CUE-D95, CUE-D75, E-HL10DS, SB-U98, SB-U50, SL-F70, SL-F50, SL-VBD96, SL-VBD64, SSL-JVC75, SSL-JVC50, NP-9X, SB-U98/PD(serial No.BD1Cxxxxxxx), SB-U50/PD(serial No.BC1Cxxxxxxx)

- Company Name :

IDX Company, Ltd.

- Address :

6-28-11 Shukugawara, Tama-ku, Kawasaki-shi,Kanagawa-ken, 214-0021 Japan

- Telephone number :

+81-44-850-8801

- FAX number :

+81-44-850-8838

- Emergency Telephone Number :

+81-44-850-8831 (Technical Development. Direct)

### 2. HAZARDS IDENTIFICATION

#### For cell

For the battery cell, chemical materials are stored in a hermetically sealed metal or metal laminated plastic case, designed to withstand temperatures and pressures encountered during normal use. As a result, during normal use, there is no physical danger of ignition or explosion and chemical danger of hazardous materials' leakage.

However, if exposed to a fire, added mechanical shocks, decomposed, added electric stress by miss-use, the gas release vent will be operated. The battery cell case will be breached at the extreme, hazardous materials may be released.

Moreover, if heated strongly by the surrounding fire, acrid gas may be emitted.

#### - GHS Classification : Not available

(This products is outside the scope of GHS system since it's considered as an "article".)

#### - Most important hazard and effects

Human health effects:

- Inhalation :	The steam of the electrolyte has an anesthesia action and stimulates a
	respiratory tract.
- Skin contact :	The steam of the electrolyte stimulates a skin. The electrolyte skin contact
	causes a sore and stimulation on the skin.
- Eye contact :	The steam of the electrolyte stimulates eyes. The electrolyte eye contact
	causes a sore and stimulation on the eye. Especially, substance that

causes a strong inflammation of the eyes is contained.

Environmental effects : Since a battery pack remains in the environment, do not throw out it into the environment.

- Specific hazards:

If the electrolyte contacts with water, it will generate detrimental hydrogen fluoride. Since the leaked electrolyte is inflammable liquid, do not bring close to fire.

### For molding case

According to GHS Classification

- Classification : Not Classification
- Possible hazards : No specific dangers known

## **3. COMPOSITION / INFORMATION ON INGREDIENTS**

#### For cell

- Substance or preparation : Preparation

- Information about the chemical nature of product:\*1

Portion	Material name	Concentration range (wt %)
Positive electrode	Lithium transition metal oxidate (Li[M]m[O]n *2)	20~60
Positive electrode's base	Aluminum	1~10



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

Negative electrode	Carbon	10~30
Negative electrode's base	Copper	1~15
Electrolyte	Ethyl methyl carbonate Diethyl carbonate Ethylene carbonate Lithium hexafluorophosphate	5~25
Outer case	Aluminum, Iron, aluminum laminated plastic	1~30

\*1 Not every product includes all of these materials.

\*2 The letter M means transition metal and candidates of M are Co, Mn, Ni and Al. One compound includes one or more of these metals and one product includes one or more of the compounds. The letter m and n means the number of atoms.

#### For molding case

- Chemical Name :	Polycarbonate based on bisphenol A		
- Composition :	Polycarbonate more than 81 wt%(CAS No.25971-63-5)		
	Flame Retardant less than 12 wt%		
	Elastomer less than 7 wt%		
- Chemical Formula :	[-0-C6H4-C(CH3)2-C6H4-0-CO-]n-		
- CAS Registry No. :	25971-63-5		

### 4. FIRST-AID MEASURES

#### For cell

#### Spilled internal cell materials

- Inhalation :
- Skin contact :
- Eye contact :

Make the victim blow his/her nose, gargle. Seek medical attention if necessary.

Remove contaminated clothes and shoes immediately. Wash extraneous matter or contact region with soap and plenty of water immediately. Do not rub one's eyes. Immediately flush eyes with water continuously for at least 15 minutes. Seek medical attention immediately.

#### A battery cell and spilled internal cell materials

Wash out mouth thoroughly. Do not make the victim vomit, unless instructed by medical personnel. Seek medical attention immediately.

#### For molding case

- Inhalation :

- Ingestion :

If fumes are inhaled, remove person to fresh air. If breathing is difficult, get medical attention.

- Ingestion :

This product does not show significant acute toxicity. Get medical attention if considerable amounts of this product are ingested.



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

- Skin contact :
- Eye contact :

Wash contaminated skin with soap and water after contact with processing vapors and fumes. Immediately cool contaminated skin with water and get medical attention after contact with molten resin. Flush the eyes with plenty of water without rubbing the eyes with hands. Get medical attention if irritation persists.

### 5. FIRE-FIGHTING MEASURE

- For cell
- Suitable extinguishing media :
- Specific hazards :
- Specific methods of fire-fighting :

Plenty of water, carbon dioxide gas, nitrogen gas, chemical powder fire extinguishing medium, and fire foam. Corrosive gas may be emitted during fire.

When the battery burns with other combustibles simultaneously, take fire-extinguishing method which corresponds to the combustibles. Extinguish a fire from the windward as much as possible.

- Special protective equipment for firefighters: Refer to Section 8 - EXPOSURE CONTROLS /

PERSONAL PROTECTION (WHEN THE ELECTROLYTE LEAKS)

#### For molding case

- Special firefighting procedures :

This product is a combustible thermoplastic material which will melt and drip when ignited and gives off combustion product mainly consisting of carbon dioxide carbon monoxide. Formation of traces of aliphatic and aromatic hydrocarbons, aldehydes, acids, phenol and phenol derivatives may occur. Fire-men have to wear self-containing breathing apparatus. Water spray or other Class A extinguishing agent.

- Extinguishing media :

### 6. ACCIDENTAL RELEASE MEASURES

Spilled internal cell materials, such as electrolyte leaked from a battery cell, are carefully dealt with according to the followings.

- Precautions for human body :

- Environmental precautions :

- Prevention of secondary hazards :

- Method of cleaning up :

Section 8 -EXPOSURE CONTROLS / PERSONAL PROTECTION (WHEN THE ELECTROLYTE LEAKS)). Do not inhale the gas as much as possible. Moreover, avoid touching with as much as possible.

Remove spilled materials with protective equipment (refer to

Do not throw out into the environment.

The spilled solids are put into a container. The leaked place is wiped off with dry cloth.

Avoid re-scattering. Do not bring the collected materials close to fire.



#### In general for molding case

Sweep or gather up product and place in proper container for disposal or recovery. Do not discard in sewers or waterways because fish may eat pallets, resulting in obstruction of their digestive tracts.

### 7. HANDLING AND STORAGE

### - Handling suggestions

#### For cell

- Do not connect the positive terminal to the negative terminal with electrical wire or chain.
- Avoid polarity reverse connection when installing the battery to an instrument.
- Do not wet the battery with water, seawater, drink or acid; or expose to strong oxidizer.
- Do not damage or remove the battery case.
- Keep the battery away from heat and fire.
- Do not disassemble or reconstruct the battery; or solder the battery directly.
- Do not give a mechanical shock or deform.
- Do not use unauthorized charger or other charging method. Terminate charging when the charging process doesn't end within specified time.
- In the case of charging, use only dedicated charger or charge according to the conditions specified by IDX.

#### For molding case

Avoid breathing processing fumes and vapors. Processing fumes and vapors may cause eye, skin and respiratory tract irritation, and in case of overexposure, nausea and headache. Clean dust form cutting and sanding operation to prevent its accumulation, since it may cause spark due to statics electricity or dust explosion. Properly ground air transportation lines including hoppers, bad filters to prevent accumulation of static electricity.

#### - Storage

#### For cell

- Do not store the battery with metalware, water, seawater, strong acid or strong oxidizer.
- Make the charge amount less than or equal to 50% then store at  $-20 \sim 40$  degree C in a dry (humidity:  $45 \sim 85\%$ ) place.

Since deterioration will be faster in the high temperature range than in the low temperature range, so do not keep it in the high temperature range beyond the period that is specified by the seller or owner.

 Use insulative and adequately strong packaging material to prevent short circuit between positive and negative terminal when the packaging breaks during normal handling. Do not use conductive or easy to break packaging material.

#### For molding case

Store this product in place not subject to direct sunlight or elevated temperatures or where there are no ignition sources. Take measures to prevent an accident due to static electricity from occurring.



### 8. EXPOSURE CONTROLS / PERSONAL PROTECTION (WHEN THE ELECTROLYTE LEAKS)

#### For cell

- Control parameters : ACGIH has not been mentioned control parameter of electrolyte.
- Personal protective equipment.
  - ·Respiratory protection : Respirator with air cylinder, dust mask.
  - ·Hand protection : Protective gloves.
  - •Eye protection : Goggle or protective glasses designed to protect against liquid splashes. •Skin and body protection :Working clothes with long sleeve and long trousers.

### For molding case

### - Personal protections

•Respiratory protection : Avoid breathing dust, vapors or fumes.

·Eye protection :

Use NIOSH/OSHA approved respiratory protection equipment(full facepiece recommended) when airborne exposure limits are exceeded. Does not cause significant eye irritation or eye toxicity requiring special protection, except when in molten state. Use good industrial practice to avoid eye contact. Processing of this product releases vapors or fumes which may cause eye irritation. Where there is significant potential for eye contact, wear appropriate eye protection and have eye flushing equipment available.

·Skin protection :

- Does not present a significant skin concern requiring special protection at room temperature. Minimize skin contamination by following good industrial hygiene practice. Processing of this product releases vapors or fumes which may cause skin irritation. Wash hands and contaminated skin thoroughly after contact with processing vapors or fumes. Wear rubber glove when handling molten resin.
- ACGIH : American Conference of Governmental Industrial Hygienists, Inc.NIOSH : National Institute for Occupational Safety and HealthOSHA : Occupational Safety & Health Administration

# 9. PHYSICAL AND CHEMICAL PROPERTIES

### For cell

- Appearance
  - Physical stat :
  - ·Form :
  - ·Color :
  - ·Odor :

Solid. Cylindrical. Metallic color(without tube if it has tube). No odor.

### For molding case

- Appearance :
- Boiling point :

Pellet. Not applicable.



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

- flash point :
- Ignition point :
- Vapor pressure :
- Melting point :
- Specific gravity :
- Oxidizability :
- Flammability :
- Explosion Limit :
- Solubility in water :
- Odor :

> 550°C Not applicable. Not applicable. 1.2 None under normal handling conditions. combustible. Not applicable. Insoluble. None.

### **10. STABILITY AND REACTIVITY**

### For cell

- Stability :	Normally stable unless a strong shock is applied or heated strongly.	
- Possibility of hazardous rea	actions: Damage to the container may cause leakage of contents.	
	Contents may leak or ignite due to temperature rise.	
- Conditions to avoid:	Crushing or deformation, use and storage at 80 degree C or higher or at	
	high humidity. Usage at a voltage or a current outside the rating and	
	external short circuit.	
- Incompatible materials:	Conductive material such as water or metal pieces. Oxidizing agent such	
	as bleach.	
- Hazardous decomposition products : Acrid or harmful gas is emitted during fire.		

### For molding case

- Thermal decomposition : Decomposition begins at 380°C.

none.

> 520°C

- Reactivity with water : none.
- Self-reactivity :
- Hazardous decomposition products : Smoldering or incomplete combustion leads to the formation of toxic gas mixture such as carbon dioxide, carbon monoxide and traces of aliphatic and aromatic hydrocarbons, aldehydes, acids, phenol and phenol derivatives. - Hazardous reaction :

No hazardous reaction observed.

### **11. TOXICOLOGICAL INFORMATION**

#### For cell

#### **Organic Electrolyte**

- Acute toxicity :

LD50, oral - Rat 2,000mg/kg or more. Irritative to skin and eye.

#### For molding case

- Irritating nature :

- Skin corrosivity, Irritation : None



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

- Acute Toxicity, Sub-acute toxicity, Chronic Toxicity, Mutagenic effects : Not known

- Carcinogenic effects : IARC group 3 (not classifiable as to its carcinogenicity to humans)

#### **12. ECOLOGICAL INFORMATION**

#### For cell

- Persistence / degradability : Since a battery cell and the internal materials remain in the environment, do not bury or throw out into the environment.

### For molding case

Relevant information is not available.

### **13. DISPOSAL CONSIDERATIONS**

- Recommended methods for safe and environmentally preferred disposal :

#### Product (waste from residues)

Specified collection or disposal of lithium ion battery is required by the law like as "battery control law" in several nations. Collection or recycle of the battery is mainly imposed on battery's manufacturer or importer in the nations recycle is required.

#### **Contaminated packaging**

Neither a container nor packing is contaminated during normal use. When internal materials leaked from a battery cells contaminates, dispose as industrial wastes subject to special control.

#### **14. TRANSPORT INFORMATION**

In the case of transportation, avoid exposure to high temperature and prevent the formation of any condensation. Take in a cargo of them without falling, dropping and breakage. Prevent collapse of cargo piles and wet by rain. The container must be handled carefully. Do not give shocks that result in a mark of hitting on a batteries. Please refer to Section 7 – HANDLING AND STORAGE also.

#### **UN classification**

- UN Number and proper shipping name :

UN3480 "Lithium ion batteries " [ or UN3481 "Lithium ion batteries packed with equipment " or UN3481 "Lithium ion batteries contained in equipment"].

#### [Watt-hour rating is excess of 160Wh]

CUE-D300, DUO-C198, DUO-C190 :

Class9 Dangerous Goods (PI965 section IA) Packing group 2 Cargo Aircraft Only

Not permitted spare batteries in carry-on baggage.



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

#### [Watt-hour rating is excess of 100Wh but not exceeding 160Wh]

IPL-150, DUO-C150, DUO-150, CUE-D150 :

Class9 Dangerous Goods (PI965 section IA) Packing group 2 Cargo Aircraft Only Maximum of two spare batteries in carry-on baggage only.

#### [Watt-hour rating is not more than 100Wh]

IPL-98,DUO-C98,DUO-C95,DUO-95,CUE-D95,CUE-D75,E-HL10DS,SB-U98,SB-U50,SL-F50, SL-F70,SL-VBD96,SL-VBD64,SSL-JVC75,SSL-JVC50,NP-9X,SB-U98/PD,SB-U50/PD :

Class9 Dangerous Goods (PI965 section IB)

Cargo Aircraft Only

Exempted Dangerous Goods (PI965 section 2) is 2 batteries per one packaging. UN Specification packaging is not required. Packaging must be test for 1.2m drop test. Maximum of 20 spare batteries in carry-on baggage only.

All IDX Li-ion batteries have Wh rating marked on notation.

Batteries capacity is must be transport at a state of charge(SoC) not exceeding 30% of the their rated capacity.

\* Although this product meets the criteria of "dangerous goods" and are classified "lithium ion batteries", depending on the battery's total capacity in the packaging, etc., they may not be subject to the fully regulated provisions.

#### Regulation depends on region and transportation mode

 Worldwide, Air transportation : ICAO/IATA-DGR [packing instruction 965 section IA, Section IB] (when shipping batteries "packed with" or "contained in" equipment, use packing instruction 966 or 967 as appropriate.)

- Worldwide, Ocean transportation : IMO-IMDG Code [special provision 188]
- Europe, Ground transportation : ADR [special provision 188]
- \* Instructions or provision in the box brackets are conditions to make the battery cell exempted from full regulation.

### **15. REGULATORY INFORMATION**

Regulations specifically applicable to the product:
US Department of Transportation 49 Code of Federal Regulations [USA]
Wastes Disposal and Public Cleaning Law [Japan]
Law for Promotion of Effective Utilization of resources [Japan]



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

### **16. OTHER INFORMATION**

- The information contained in this Safety data sheet is based on the present sate of knowledge and current legislation.
- This safety data sheet provides guidance on health, safety and environmental aspects of the product and should not be construed as any guarantee of technical performance or suitability for particular applications.
- IDX makes no warranty, expressed or implied regarding the accuracy of these data or the results to be obtained from the use thereof. IDX assumes no responsibility for injury from the use to the product described herein.

#### - Reference

- Dangerous Goods Regulations 66<sup>th</sup> Edition Effective from 1 January 2025: International Air Transport Association (IATA)
- · IMDG Code -2022 and 2024 Edition: International Maritime Organization(IMO)
- Agreement concerning the International Carriage of Dangerous Goods by Road -2023(ADR):The United Nations Economic Commission for Europe(UNECE)

SDS of raw materials prepared by the manufactures

29th edition: January 1, 2025

Prepared and approved by Research and Development Division IDX Company, Ltd.



Page 10



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv

Issued: January 1, 2025

No. XC19T0095-13

# SAFETY DATA SHEET FOR PRODUCT

# **1. PRODUCT AND COMPANY IDENTIFICATION**

- Product Name :

Lithium Ion Rechargeable Battery Pack

- Product code :

Imicro-150, Imicro-98, CUE-H90, CUE-H135, CUE-H180 DUO-C98P, DUO-C150P, DUO-C198P, ZEN-C98G, ZEN-C150G Imicro-50P, Imicro-98P, Imicro-150P, CUE-J98, CUE-J150, CUE-J198, HV-160B,HV-320B, SB-U50/PD(serial No.BC2Cxxxxxx), SB-U98/PD(serial No.BD2Cxxxxxx), SL-F50PD,SL-F70PD

- Company Name :

- Address :

IDX Company, Ltd.

6-28-11 Shukugawara, Tama-ku, Kawasaki-shi,Kanagawa-ken, 214-0021 Japan

- Telephone number :

- FAX number :

+81-44-850-8838

+81-44-850-8801

- Emergency Telephone Number : +81-44-850-8831 (Technical Development. Direct)

### 2. HAZARDS IDENTIFICATION

#### For cell

For the battery cell, chemical materials are stored in a hermetically sealed metal or metal laminated plastic case, designed to withstand temperatures and pressures encountered during normal use. As a result, during normal use, there is no physical danger of ignition or explosion and chemical danger of hazardous materials' leakage.

However, if exposed to a fire, added mechanical shocks, decomposed, added electric stress by miss-use, the gas release vent will be operated. The battery cell case will be breached at the extreme, hazardous materials may be released.

Moreover, if heated strongly by the surrounding fire, acrid gas may be emitted.

#### - GHS Classification : Not available

(This products is outside the scope of GHS system since it's considered as an "article".)

#### - Most important hazard and effects

Human health effects:

- Inhalation :	The steam of the electrolyte has an anesthesia action and stimulates a
	respiratory tract.
- Skin contact :	The steam of the electrolyte stimulates a skin. The electrolyte skin contact
	causes a sore and stimulation on the skin.
- Eye contact :	The steam of the electrolyte stimulates eyes. The electrolyte eye contact
	causes a sore and stimulation on the eye. Especially, substance that
	causes a strong inflammation of the eyes is contained.
Environmental effects :	Since a battery pack remains in the environment, do not throw out it into
	the environment.

- Specific hazards:

If the electrolyte contacts with water, it will generate detrimental hydrogen fluoride. Since the leaked electrolyte is inflammable liquid, do not bring close to fire.

### For molding case

According to GHS Classification

- Classification : Not Classification
- Possible hazards : No specific dangers known

## **3. COMPOSITION / INFORMATION ON INGREDIENTS**

For cell	NE LOL ID -
Material name	%
Aluminum Foil	2-10
Nickel compound(proprietary)	0-80
Manganese compound(proprietary)	0-15
Cobalt compound(proprietary)	0-15



Styrene-Butadiene-Rubber	<1
Polyvinylidene Fluoride(PVDF)	<5
Copper Foil	2-10
Carbon(proprietary)	10-30
Electrolyte (proprietary)	10-20
Steel, Nickel and inert materials	Remainder

#### For molding case

- Chemical Name :	Polycarbonate based on bisphenol A	
- Composition :	Polycarbonate	more than 81 wt%(CAS No.25971-63-5)
	Flame Retardant	t less than 12 wt%
	Elastomer less than 7 wt%	
- Chemical Formula :	[-0-C6H4-C(CH3)2-C6H4-0-CO-]n-	
- CAS Registry No. :	25971-63-5	

### 4. FIRST-AID MEASURES

### For cell

#### Spilled internal cell materials

- Inhalation :	Make the victim blow his/her nose, gargle. Seek medical attention if
	necessary.
- Skin contact :	Remove contaminated clothes and shoes immediately. Wash extrane

- Eye contact :

Remove contaminated clothes and shoes immediately. Wash extraneous matter or contact region with soap and plenty of water immediately. Do not rub one's eyes. Immediately flush eyes with water continuously for at least 15 minutes. Seek medical attention immediately.

#### A battery cell and spilled internal cell materials

- Ingestion :

Wash out mouth thoroughly. Do not make the victim vomit, unless instructed by medical personnel. Seek medical attention immediately.

#### For molding case

- Inhalation :

If fumes are inhaled, remove person to fresh air. If breathing is difficult, get medical attention.

- Ingestion :

This product does not show significant acute toxicity. Get medical attention if considerable amounts of this product are ingested.



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

- Skin contact :
- Eye contact :

Wash contaminated skin with soap and water after contact with processing vapors and fumes. Immediately cool contaminated skin with water and get medical attention after contact with molten resin. Flush the eyes with plenty of water without rubbing the eyes with hands. Get medical attention if irritation persists.

### 5. FIRE-FIGHTING MEASURE

- For cell
- Suitable extinguishing media :
- Specific hazards :
- Specific methods of fire-fighting :

Plenty of water, carbon dioxide gas, nitrogen gas, chemical powder fire extinguishing medium, and fire foam. Corrosive gas may be emitted during fire.

When the battery burns with other combustibles simultaneously, take fire-extinguishing method which corresponds to the combustibles. Extinguish a fire from the windward as much as possible.

- Special protective equipment for firefighters: Refer to Section 8 - EXPOSURE CONTROLS /

PERSONAL PROTECTION (WHEN THE ELECTROLYTE LEAKS)

#### For molding case

- Special firefighting procedures :

This product is a combustible thermoplastic material which will melt and drip when ignited and gives off combustion product mainly consisting of carbon dioxide carbon monoxide. Formation of traces of aliphatic and aromatic hydrocarbons, aldehydes, acids, phenol and phenol derivatives may occur. Fire-men have to wear self-containing breathing apparatus. Water spray or other Class A extinguishing agent.

- Extinguishing media :

### 6. ACCIDENTAL RELEASE MEASURES

Spilled internal cell materials, such as electrolyte leaked from a battery cell, are carefully dealt with according to the followings.

- Precautions for human body :

- Environmental precautions :

- Prevention of secondary hazards :

- Method of cleaning up :

Section 8 -EXPOSURE CONTROLS / PERSONAL PROTECTION (WHEN THE ELECTROLYTE LEAKS)). Do not inhale the gas as much as possible. Moreover, avoid touching with as much as possible.

Remove spilled materials with protective equipment (refer to

Do not throw out into the environment.

The spilled solids are put into a container. The leaked place is wiped off with dry cloth.

Avoid re-scattering. Do not bring the collected materials close to fire.



#### In general for molding case

Sweep or gather up product and place in proper container for disposal or recovery. Do not discard in sewers or waterways because fish may eat pallets, resulting in obstruction of their digestive tracts.

### 7. HANDLING AND STORAGE

### - Handling suggestions

#### For cell

- Do not connect the positive terminal to the negative terminal with electrical wire or chain.
- Avoid polarity reverse connection when installing the battery to an instrument.
- Do not wet the battery with water, seawater, drink or acid; or expose to strong oxidizer.
- Do not damage or remove the battery case.
- Keep the battery away from heat and fire.
- Do not disassemble or reconstruct the battery; or solder the battery directly.
- Do not give a mechanical shock or deform.
- Do not use unauthorized charger or other charging method. Terminate charging when the charging process doesn't end within specified time.
- In the case of charging, use only dedicated charger or charge according to the conditions specified by IDX.

#### For molding case

Avoid breathing processing fumes and vapors. Processing fumes and vapors may cause eye, skin and respiratory tract irritation, and in case of overexposure, nausea and headache. Clean dust form cutting and sanding operation to prevent its accumulation, since it may cause spark due to statics electricity or dust explosion. Properly ground air transportation lines including hoppers, bad filters to prevent accumulation of static electricity.

#### - Storage

#### For cell

- Do not store the battery with metalware, water, seawater, strong acid or strong oxidizer.
- Make the charge amount less than or equal to 50% then store at  $-20 \sim 40$  degree C in a dry (humidity:  $45 \sim 85\%$ ) place.

Since deterioration will be faster in the high temperature range than in the low temperature range, so do not keep it in the high temperature range beyond the period that is specified by the seller or owner.

 Use insulative and adequately strong packaging material to prevent short circuit between positive and negative terminal when the packaging breaks during normal handling. Do not use conductive or easy to break packaging material.

#### For molding case

Store this product in place not subject to direct sunlight or elevated temperatures or where there are no ignition sources. Take measures to prevent an accident due to static electricity from occurring.



### 8. EXPOSURE CONTROLS / PERSONAL PROTECTION (WHEN THE ELECTROLYTE LEAKS)

#### For cell

- Control parameters : ACGIH has not been mentioned control parameter of electrolyte.
- Personal protective equipment.
  - ·Respiratory protection : Respirator with air cylinder, dust mask.
  - ·Hand protection : Protective gloves.
  - •Eye protection : Goggle or protective glasses designed to protect against liquid splashes. •Skin and body protection :Working clothes with long sleeve and long trousers.

### For molding case

### - Personal protections

•Respiratory protection : Avoid breathing dust, vapors or fumes.

·Eye protection :

Use NIOSH/OSHA approved respiratory protection equipment(full facepiece recommended) when airborne exposure limits are exceeded. Does not cause significant eye irritation or eye toxicity requiring special protection, except when in molten state. Use good industrial practice to avoid eye contact. Processing of this product releases vapors or fumes which may cause eye irritation. Where there is significant potential for eye contact, wear appropriate eye protection and have eye flushing equipment available.

·Skin protection :

- Does not present a significant skin concern requiring special protection at room temperature. Minimize skin contamination by following good industrial hygiene practice. Processing of this product releases vapors or fumes which may cause skin irritation. Wash hands and contaminated skin thoroughly after contact with processing vapors or fumes. Wear rubber glove when handling molten resin.
- ACGIH : American Conference of Governmental Industrial Hygienists, Inc.NIOSH : National Institute for Occupational Safety and HealthOSHA : Occupational Safety & Health Administration

# 9. PHYSICAL AND CHEMICAL PROPERTIES

### For cell

- Appearance
  - Physical stat :
  - ·Form :
  - ·Color :
  - ·Odor :

Solid. Cylindrical. Metallic color(without tube if it has tube). No odor.

### For molding case

- Appearance :
- Boiling point :

Pellet. Not applicable.



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

- flash point :
- Ignition point :
- Vapor pressure :
- Melting point :
- Specific gravity :
- Oxidizability :
- Flammability :
- Explosion Limit :
- Solubility in water :
- Odor :

> 550°C Not applicable. Not applicable. 1.2 None under normal handling conditions. combustible. Not applicable. Insoluble. None.

### **10. STABILITY AND REACTIVITY**

### For cell

- Stability :	Normally stable unless a strong shock is applied or heated strongly.	
- Possibility of hazardous reactions: Damage to the container may cause leakage of contents.		
	Contents may leak or ignite due to temperature rise.	
- Conditions to avoid:	Crushing or deformation, use and storage at 80 degree C or higher or at	
	high humidity. Usage at a voltage or a current outside the rating and	
	external short circuit.	
- Incompatible materials:	Conductive material such as water or metal pieces. Oxidizing agent such	
	as bleach.	
- Hazardous decomposition	products : Acrid or harmful gas is emitted during fire.	

### For molding case

- Thermal decomposition : Decomposition begins at 380°C.

none.

> 520°C

- Reactivity with water : none.
- Self-reactivity :
- Hazardous decomposition products : Smoldering or incomplete combustion leads to the formation of toxic gas mixture such as carbon dioxide, carbon monoxide and traces of aliphatic and aromatic hydrocarbons, aldehydes, acids, phenol and phenol derivatives. - Hazardous reaction :

No hazardous reaction observed.

### **11. TOXICOLOGICAL INFORMATION**

#### For cell

#### **Organic Electrolyte**

- Acute toxicity :

LD50, oral - Rat 2,000mg/kg or more. Irritative to skin and eye.

#### For molding case

- Irritating nature :

- Skin corrosivity, Irritation : None



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

- Acute Toxicity, Sub-acute toxicity, Chronic Toxicity, Mutagenic effects : Not known

- Carcinogenic effects : IARC group 3 (not classifiable as to its carcinogenicity to humans)

#### **12. ECOLOGICAL INFORMATION**

#### For cell

- Persistence / degradability : Since a battery cell and the internal materials remain in the environment, do not bury or throw out into the environment.

### For molding case

Relevant information is not available.

### **13. DISPOSAL CONSIDERATIONS**

- Recommended methods for safe and environmentally preferred disposal :

#### Product (waste from residues)

Specified collection or disposal of lithium ion battery is required by the law like as "battery control law" in several nations. Collection or recycle of the battery is mainly imposed on battery's manufacturer or importer in the nations recycle is required.

#### **Contaminated packaging**

Neither a container nor packing is contaminated during normal use. When internal materials leaked from a battery cells contaminates, dispose as industrial wastes subject to special control.

### **14. TRANSPORT INFORMATION**

In the case of transportation, avoid exposure to high temperature and prevent the formation of any condensation. Take in a cargo of them without falling, dropping and breakage. Prevent collapse of cargo piles and wet by rain. The container must be handled carefully. Do not give shocks that result in a mark of hitting on a batteries. Please refer to Section 7 – HANDLING AND STORAGE also.

#### **UN classification**

- UN Number and proper shipping name :

UN3480 "Lithium ion batteries " [ or UN3481 "Lithium ion batteries packed with equipment " or UN3481 "Lithium ion batteries contained in equipment"].

#### [Watt-hour rating is excess of 160Wh]

CUE-H180,DUO-C198P,CUE-J198,HV-320B

Class9 Dangerous Goods (PI965 section IA)

Packing group 2

Cargo Aircraft Only

Not permitted spare batteries in carry-on baggage.



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

#### [Watt-hour rating is excess of 100Wh but not exceeding 160Wh]

Imicro-150,CUE-H135,DUO-C150P,ZEN-C150G,Imicro-150P,CUE-J150,HV-160B Class9 Dangerous Goods (PI965 section IA) Packing group 2 Cargo Aircraft Only

Maximum of two spare batteries in carry-on baggage only.

#### [Watt-hour rating is not more than 100Wh]

Imicro-98,CUE-H90,DUO-C98P,ZEN-C98G,Imicro-50P,Imicro-98P,CUE-J98, SB-U50/PD,SB-U98/PD,SL-F50PD,SL-F70PD

Class9 Dangerous Goods (PI965 section IB)

Cargo Aircraft Only

Exempted Dangerous Goods (PI965 section 2) is 2 batteries per one packaging. UN Specification packaging is not required. Packaging must be test for 1.2m drop test. Maximum of 20 spare batteries in carry-on baggage only.

All IDX Li-ion batteries have Wh rating marked on notation.

Batteries capacity is must be transport at a state of charge(SoC) not exceeding 30% of the their rated capacity.

\* Although this product meets the criteria of "dangerous goods" and are classified "lithium ion batteries", depending on the battery's total capacity in the packaging, etc., they may not be subject to the fully regulated provisions.

#### Regulation depends on region and transportation mode

 Worldwide, Air transportation : ICAO/IATA-DGR [packing instruction 965 section IA, Section IB] (when shipping batteries "packed with" or "contained in" equipment, use packing instruction 966 or 967 as appropriate.)

- Worldwide, Ocean transportation : IMO-IMDG Code [special provision 188]
- Europe, Ground transportation : ADR [special provision 188]

\* Instructions or provision in the box brackets are conditions to make the battery cell exempted from full regulation.

### **15. REGULATORY INFORMATION**

Regulations specifically applicable to the product:
US Department of Transportation 49 Code of Federal Regulations [USA]
Wastes Disposal and Public Cleaning Law [Japan]
Law for Promotion of Effective Utilization of resources [Japan]



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/

### **16. OTHER INFORMATION**

- The information contained in this Safety data sheet is based on the present sate of knowledge and current legislation.
- This safety data sheet provides guidance on health, safety and environmental aspects of the product and should not be construed as any guarantee of technical performance or suitability for particular applications.
- IDX makes no warranty, expressed or implied regarding the accuracy of these data or the results to be obtained from the use thereof. IDX assumes no responsibility for injury from the use to the product described herein.

#### - Reference

- Dangerous Goods Regulations 66<sup>th</sup> Edition Effective from 1 January 2025: International Air Transport Association (IATA)
- · IMDG Code -2022 and 2024 Edition: International Maritime Organization(IMO)
- Agreement concerning the International Carriage of Dangerous Goods by Road -2023(ADR):The United Nations Economic Commission for Europe(UNECE)

SDS of raw materials prepared by the manufactures

13th edition: January 1, 2025

Prepared and approved by Research and Development Division IDX Company, Ltd.



IDX Company, Ltd. 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken, 214-0021 JAPAN TEL: +81-44-850-8801 FAX: +81-44-850-8838 http://www.idx.tv/